

## BC-50B

### Automatic No-Bark Collar

1. Set Up Collar: Insert 6v alkaline battery, positive side up
2. Auto – Set Technology, the No Bark Collar automatically sets itself at the appropriate stimulation that quiets your dog. It also gives your dog a two – second “learning time – out” between stimulations.

---

#### Troubleshooting Tips

1. Probe selection: Both probes need to be same length (short or long)
2. Check battery: Change battery Battery life = 2-6 months  
Make sure battery is positioned positive side up
3. Check collar: Rub the probes on a rough surface; see if light comes on.  
Receiver is working if a red light comes on briefly when rubbed
4. Collar fit: 1 finger allowed to slide under strap at back of dog's neck  
Probes positioned 1” above or below dog's Adam's apple  
Outside probes must make skin contact
5. Reset Stimulation: Take battery out of the collar and leave it out for 1 minute

## BC-50B Features

Battery:	6-volt alkaline (part # BAT-001)	
Collar:	Water-resistant and measures 2" wide x 1.25" tall x 1.25" thick Nylon strap Battery screw caps included in RK-12.	
Grommets:	Located at base of stimulation probes	
Lights:	Blinking red light once every 5 seconds Pulsating red light  Solid Red	Low battery indicator Reset period after delivering stimulation Delivering stimulation