

BT-502A Basic Trainer Features

Batteries: Collar uses 6v alkaline Battery life = 48-72 hours
Hand-held transmitter uses 12v alkaline Battery life = 2-3 months

Collar: Battery replaceable, water-resistant, weather-resistant
Omni-directional signal
Measures 2" wide x 1.5" tall x 1" thick and weighs 4.0 oz.
Red or blue nylon strap with reflector strip and quick-release clip
Red = 1700458-6 Blue = 1700458-4
Battery screw caps = included in RK-12

Collar Lights: Green blinking = On and ready
Yellow blinking = Programming Mode
Red pulsating = Stimulation
Yellow pulsating = Low battery

Hand-Held Transmitter: can operate 2 collars and is water-resistant
Measures 1.75" wide x 3.5" tall x .625" thick and weighs 2.8 oz.
Preset stimulation (low, medium, high, max)
Tone options (tone, no tone, delay)
Up to 150 yard range in flat, open terrain
12v alkaline
Low battery indicator is pulsating red light on transmitter
Battery plug = 1700112-1

Hand-Held Transmitter Lights: Green pulsating = Activating
Yellow solid = Programming Mode
Red pulsating = Low battery

Range: Up to 150 yards in flat, open terrain

Stimulation: Preset for low, medium, high and max

Video-52 Dog Star training video

BT-502A Basic Trainer Troubleshooting Tips

Walk through programming and synchronization.

Neither collar works on Dog 1 side of transmitter: Transmitter problem

Collar 1 will not stimulate on Dog 1 or Dog 2 side but Collar 2 stimulates on both sides:
Collar 1 problem

Both collars stimulate simultaneously: Reprogram and synchronize Collar 1 with Collar 2 off
Then reprogram and sync Collar 2 with Collar 1 off

Range is Low: Check battery in hand-held transmitter
Reprogram and resynchronize

No Stimulation: Reprogram and resynchronize collar with hand-held remote

Collar is locked up: Remove battery; check voltage of battery
Replace battery if voltage is low.