

Bark Inhibitor BC-100

(Rechargeable collar with 3 probes)

1. Set Up Collar: Charge 8-12 hours
2. Program Stimulation: Hold magnet to red paper dot → solid red light
Pull magnet away → flashes previously set level
(Within 5 sec) hold the magnet to red paper dot → flashes 1-7
Pull magnet away when # flashes = desired stimulation level
Wait for confirmation
(Defaults to Stimulation Level 1)

Bark Inhibitor BC-100 Features

Adapter: 12v, 200mAmp, DC preferred

Collar: Waterproof, rechargeable, and measures 2" wide x 1.5" tall x .875" thick
Full charge takes 8-12 hours and lasts 30-72 hours of use
Nylon strap

Grommets: Located at base of stimulation probes

Manual: 2400263-1

Not Included: Probe wrench, test light, video

"O" Ring: Located at base of vibration probe

Probes: Packaged with 2 long metal, 2 short metal, 1 long vibration, 1 short vibration

Troubleshooting Tips

Dog not receiving correction / collar activating inappropriately:	All 3 probes need to be same length (short or long) Center probe should be 1/16" higher than outside probes No metal on dog
No light when charging:	Check outlet and adapter Some units have a light when charging; some do not
Check collar:	Rub the center probe on a rough surface; see if light comes on.
Collar fit:	1-2 fingers allowed to slide under strap at back of dog's neck Probes positioned 1" above or below dog's Adam's apple Outside probes must make skin contact
Locked up:	Place collar on charger for 5 min → light out → recharge
Not taking a charge:	Check outlet Check adapter and verify it is 12-volt, < 200 mAmp
Not holding a charge:	Completely drain collar and recharge 8-12 hours
Losing Programming:	Check for magnetic Staywell door or use of other magnets